NSN 2915-00-936-9502

Repairability:

Main Fuel Su Stop Valve Assembly - Page 1 of 1



When repair is beyond lower level maintenance capability, evacuate the item to depot. disposal is not authorized below wholesale level.